

# XTZ REMOTE

for Sub Amp1 DSP & W12 DSP

## XTZ-Remote

XTZ-Remote is software allowing you to control SUB AMP 1 DSP from a PC, via the RS 232 port. You can sit in listening position and do all settings.

The program is included in the price but you need to download the newest software from [www.xtz.se](http://www.xtz.se)

Following setting is needed to get XTZ-Remote to work,

**Port:** Com 1  
**Bits per second:** 9600  
**Parity:** None  
**Stop bits:** 1  
**Flow control:** None

If using a USB-> RS 232 converter, make sure the port is changed to COM1.

